

BLUETOOTH AUDIO ADAPTER

REF: E094-1 22-08-14

INSTALLATION INSTRUCTIONS

The Bluetooth Audio Adapter provides wireless Bluetooth connections and two separate hard wired audio connections to a Lynx Micro System headset.

The Bluetooth Audio Adapter is powered from a Micro System headset or from a Micro System Radio/Power Interface and does not require charging.

NOTE:

When connected to a single headset, a Headset Switching Adapter must be used to switch-on the assembly.

If a second headset is connected directly to the Bluetooth Audio Adapter using a Coupling Adapter, the second headset will not transmit when using a telephone.

BLUETOOTH:

The Bluetooth function is turned on and off using the **POWER** button.

1. To turn Bluetooth on, press and hold the **POWER** button for five seconds.

The status indicator will flash blue every two seconds.

2. To turn Bluetooth off, press and hold the **POWER** button for ten seconds or disconnect the adapter.

PAIRING:

Before the adapter can be used with another device the two devices must be 'paired' together; this establishes two way communication between the two devices and stores the connection information for future use.

To pair the adapter with a telephone:

1. Make sure that the adapter is turned off.
2. Set the adapter to pairing mode (discoverable) by pressing and holding the **POWER** button for eight seconds.

The status indicator will flash red and blue.

3. Use the telephone's Bluetooth pairing procedure to look for new devices.

The adapter will appear in the list of available devices as: **Lynx BTA-2**

4. Select the adapter (Lynx BTA-2) and enter the PIN passcode: **0000**


The status indicator will revert to flashing blue every two seconds to indicate that the pairing has been successful.



WARNING:

The Bluetooth Audio Adapter is designed specifically for use with equipment manufactured by Lynx Avionics; do not use with other makes and models of equipment.

CONNECT TO
HEADSET
SOCKET



CONNECT TO
HEADSET

AUDIO SOCKET

POWER BUTTON

4. To redial the last number called, press and hold the **TALK** button until you hear a tone.

5. To adjust the headset volume, press and hold the **UP** or **DOWN** button.

It can take up to sixty seconds for two devices to establish a connection the first time that they are used together.

The adapter can store pairing information for eight Bluetooth devices but only one device can be connected at a time. Any of the eight paired devices can initiate a connection to the adapter but the adapter will only automatically reconnect to the last device used.

Once the adapter has been paired and connected to a device, it will reconnect automatically whenever it is within range.

MAKING CALLS:

The adapter supports the Bluetooth Handsfree profile and, depending on the telephone, will provide at least the minimum basic functions listed below:

1. To answer a call or end a call, press the **TALK** button for less than one second.
2. To simplify telephone use in an aircraft, the adapter will automatically answer a call after four rings. To prevent the adapter from answering a call, immediately press and hold the **TALK** button until you hear a tone.
3. To transfer a call back to the telephone, press and hold the **TALK** button until you hear a tone.

MUSIC:

To pair with a music player, follow the instructions for pairing with a telephone. If the music player does not have a screen menu, the two devices will connect if they are both put into pairing mode at the same time.

1. To stop music playback, press the **TALK** button for less than one second.

2. To move forward or backward through music tracks use the **UP** or **DOWN** button.

AUDIO SOCKETS:

The adapter can be used with Lynx Audio Input/Output Leads, Audio Output Leads or Mobile Telephone Leads. The leads may be used in any combination.

For connection to recording devices, the adapter provides output at Microphone level (with Audio Input/Output Lead) or Line Level (with Audio Output Lead).

AUDIO MUTE:

All of the audio connections to the adapter can be isolated at any time using the Audio Mute switch.

IMPORTANT

READ THIS INFORMATION CAREFULLY BEFORE
ATTEMPTING TO USE THIS ITEM OF EQUIPMENT